Specification and Installation Guide:
Model KTWG
White Splash Guard
for Saniflow Hand Dryers

1. Clean wall with Isopropyl Alcohol prior to installation and make sure the surface is dry and free of debris.

2. Remove one strip and apply double-sided tape to the textured side of Splash Guard until all four strips are installed. See illustration for details

3. Adhere to the wall beneath hand dryer

